



START


Getting Started



1. Touch the AMX screen




2. Select an input source
(Allow 30 seconds for projector to turn on)



3. Adjust lights & volume




Lighting Controls



1. Touch "light bulb" button



2. Adjust lighting zones



3. Touch "back" button
(returns to previous screen)




Volume Controls



1. Select an input source



2. Adjust volume




Note:
When using the computer or laptop, remember to also adjust volume controls in the task bar and in the media player.

EXIT

Shutting Down



1. Touch "System Off" button



2. Select "Yes"

(This powers down the projector and sets the touchpanel back to the default "UCI" screen)



Information

For Questions and Assistance:

Please call **x48833**

Before Leaving, Please:

- Log off of the computer (do not power off the PC)
- Take all personal belongings with you, including computer accessories and media